## HTK Ultra Strip® 100





### 100% biodegradable!

# Remarkably effective solvent composition for removing of cured HTK Ultra Bond® 100

It initiates and promotes flaking and breaking rather than pure solvent action. HTK Ultra Strip® 100 is most effective when used hot. Most metals or platings will not be discoloured or attacked. HTK Ultra Strip® 100 is reusable several times. HTK Ultra Strip® 100 is completely miscible with water and is 100% biodegradable.

#### **Properties**

- HTK Ultra Strip® 100 is a mobile liquid with a mild pleasant odour.
- Low Toxicity: LD50 = 70cc/Kg
- Boiling Point: 200°C
- Flash Point (open cup): 95°C
- Auto Ignition Temperature: 350°C

- Vapour Pressure: at 24°C 1 mm Hg
  - at 93°C 18 mm Hg at 177°C 375 mm Hg
- CAS No 872-50-4
- EG-Index No 606-021-00-7

#### Application

HTK Ultra Strip® 100 will disintegrate HTK Ultra Bond® 100 when used hot. The preferred temperature range for use is 105°C to 175°C. It is not a selective system and will attack certain thermoplastics including wire coating insulations and some thermoset coatings.

It does not attack most metals or platings. HTK Ultra Strip® 100 should be poured into a suitable glass, aluminium or stainless steel container.

The container is then placed on a covered hot plate or in a water bath, etc., and heated to 120-170°C. For removing the HTK Ultra Strip® 100 the components will be dipped into the heated HTK Ultra Strip® 100 – Liquid for some minutes.

Remove the component with a metal tong and wash it with water or ketone solvent. Now you may blow off loosened HTK Ultra Bond<sup>®</sup> 100 flash with compressed air. If applicable repeat the procedure.

#### Disposal

HTK Ultra Strip® 100 can be diluted with 10 times ist volume of water before discarding. It is also miscible with most common solvents. HTK Ultra Strip® 100 may be discharged into aqueous waste streams. Consult prevaling pollution regulations before discharging into the waste stream. HTK Ultra Strip® 100 is 100% biodegradable.

#### **Availability**

HTK Ultra Strip® 100 is available in 200 ml containers. The Shelf Life is approx. 6 month.

#### HTK Hamburg GmbH

Oehleckerring 32 • 22419 Hamburg Phone: +49 (0)40 - 600 38 38 - 0 • Fax: +49 (0)40 - 600 38 38 - 99

info@htk-hamburg.com

© Copyright 2019 - All contents of this document, in particular Texts, photographs and graphics are protected by copyright

All rights, including reproduction, publication, processing and translation are reserved, HTK Hamburg GmbH

Please contact HTK Hamburg GmbH if you would like to use the contents of this document



